





Follow the prescribed installation process
 Deviating from the process can cause unpredictable system behavior and can damage your equipment.

1. Unpack & Inspect




2. Verify Shipment




3. Install Instrument

See back page for accessories.



For detailed installation instructions, read the manual.



Visit www.keysight.com to get the latest manual.

- Documents in the box:**

 - Calibration Certificate sheet
 - Safety Information
 - Safety Information Supplement
 - Safety Precautions for Lithium-ion Battery, for B2983B/B2987B
 - Quick Reference sheet
 - Quick Startup Poster (this sheet)



Latest declaration of conformity

Declarations of Conformity for this product and for other Keysight products may be downloaded from the Web. Go to www.keysight.com/go/conformity. You can then search by product number to find the latest Declaration of Conformity.

Latest information


To get the latest firmware, software, electronic manuals, and support information, go to www.keysight.com. You can then search them by product number.



Li-ion battery for B2983B/B2987B



USB cable



Power cord



Alligator clips for B2985B/B2987B



Earthing wire for B2983B/B2987B



Extension leads for B2985B/B2987B



Triaxial cable



Interlock connector head, 4-pin for B2985B/B2987B



Humidity probe connector head, 5-pin for B2985B/B2987B



Thermocouple for B2985B/B2987B



Triaxial open cap

One cap for B2981B/B2983B
Two caps for B2985B/B2987B

Banana-to-lug cable

